



In the to scale example above, the signing layout is only just "on the map". A longer site or a higher speed limit would require either a larger drawing frame or a smaller scale map.  
An alternative is to show the layout schematically and to include the map on the drawing with perhaps only the DATUM points and the work area shown.